

Assembly Instruction – How to assemble the handlebar on the shaft:

Step 1: You can find 4pcs M8×35 Inner hex screws inside the accessory package;

Step 2: Insert these 4 screws to the holes on the handlebar;

Step 3: Use M6 hex key to fasten these screws to the screw thread on the back of shaft;

Step 4: Use torque wrench to fasten the screws, torque force value should be 10Nm;

Step 5: Insert the screw caps on the screws.

