



## PRO7 Assembly Instructions

### **Carton Contents:**

#### Column Carton:

- 1 – Column Assembly
- 1 – Column Dust Cover

#### Platform / Iron Base Carton:

- 1 – Platform Assembly
- 1 – Platform Dust Cover
- 1 – Line Cord
- 1 – User Manual
- 1 – Rubber / Foam Mat
- 2 – Straps
- 2 – proMOTION Handles
- 3 – Column Securing Bolts with Washers






**Tools Needed:**

1 - 16mm or 5/8 Wrench or Socket Set

1 - Riser 4-5" in height

**STEP 1:**


Remove Platform / Iron Base from Carton and set on top of riser 4-5" clearance is recommended.







## STEP 2:

Set the column next to the Platform / Iron Base and make wire connections; 2 – Yellow/green to Ground (Earth), 1 – Brown and 1 – Blue to remaining terminal (Not polarity sensitive) and finally the Multi Colored cable from the column attached to the Multi Colored cable on the platform.



POWER  PLATE®





- ① **Multi-Colored cable: Control Panel signal cable**
- ② **Blue cable: Filter power cable**
- ③ **Brown cable: Filter power cable**
- ④ **Yellow/green cable I: Filter ground cable**
- ⑤ **Yellow/green cable II: Control Panel ground cable**



### STEP 3:

Attach the column to the platform using the supplied 3 – 16mm Platform Bolts including spring and flat washers.





#### STEP 4:

Remove completed PRO7 from riser and plug in to nearest power outlet and turn ON and test.  
Place all accessories on top of PRO7 platform or give to customer.

